







Installation & Assembly

Please relieve fluid **pressure** and allow temperature to **cool** before **removing** any hose, fittings or adapters.

Please contact our technical support team for any further

Lubricate seals and avoid over-tightening threads.


information or help with your installation.


What's Included

- 1x HEL Oil Filter Relocation Remote Head
- 1x Threaded Centre Bolt (Selectable)
- 2x Port Plug or Sensor Adapter (Selectable)
- 2x Hose Fitting Adapter (Selectable)

*Dimensions below are shown in millimeters (mm)

85.00 80.00





 \mathbb{N}

Please Note

Before operating the vehicle, it is the installer's responsibility to ensure that all components are fully tightened and secure. Failure to do so, could result in oil loss or, in the worst case, engine failure.

Contact



